

STEP 1: Attach SME base to flat surface using (whichever is applicable):
two #4 X 1/2" wood screws
four #6-32 X 3/8" machine screws
four double-sided foam tapes


When using foam tape, remove protective paper from one side and apply to SME base. Then remove remaining paper and firmly apply unit to the clean, dry, flat surface.

STEP 2: Install jacks or AXCESS series components into coupler plates. (Note: orientation of coupler plates)

STEP 3: Snap coupler plates into SME base and secure cables to SME base using the cable ties provided.


STEP 4: If raceway entry is desired, trim and break off raceway partition on SME base.

STEP 5: Attach cover to SME base using one #6-32 x 1" painted screw, one washer, and one #6-32 threaded insert as provided.




**8 PORT POSITION (SME8XX)
SHOWN WITH UMJ JACKS**

8 PORT SME
(SME8XX)



10 PORT SME
(SME10XX)



STEP 1: Attach SME base to flat surface using (whichever is applicable):
two #4 X 1/2" wood screws
four #6-32 X 3/8" machine screws
four double-sided foam tapes


When using foam tape, remove protective paper from one side and apply to SME base. Then remove remaining paper and firmly apply unit to the clean, dry, flat surface.

STEP 2: Install jacks or AXCESS series components into coupler plates. (Note: orientation of coupler plates)

STEP 3: Snap coupler plates into SME base and secure cables to SME base using the cable ties provided.


STEP 4: If raceway entry is desired, trim and break off raceway partition on SME base.

STEP 5: Attach cover to SME base using one #6-32 x 1" painted screw, one washer, and one #6-32 threaded insert as provided.




**8 PORT POSITION (SME8XX)
SHOWN WITH UMJ JACKS**


8 PORT SME
(SME8XX)



10 PORT SME
(SME10XX)



SME8/10 SURFACE MOUNT BOX INSTALLATION PROCEDURE



8 PORT SME Parts List:

Base


- 1 - SME Base
- 2 - Flat Tie Holders
- 2 - Coupler Plates
- 1 - Nameplate, Blank
- 2 - #4 x 1/2", Wood Screws
- 4 - #6-32 x 3/8", Machine Screws
- 4 - Double-sided Foam Tapes
- 2 - Cable Ties
- 1 - #6-32, Threaded Insert

Cover

- 1 - SME Cover
- 1 - #6-32 x 1", Painted Screw
- 1 - Fiber Washer
- 1 - Faceplate Window, Clear
- 1 - Faceplate Card

Tools Required:


- Phillips Screwdriver
- Razor Knife
- Straight Screwdriver



5290 Concourse Drive • Roanoke, VA 24019 USA
Phone: 540-265-0690 • TOLL FREE 800-622-7711
Fax: 540-265-0724 • www.occfiber.com

SIDE 2

SME8/10 SURFACE MOUNT BOX INSTALLATION PROCEDURE



8 PORT SME Parts List:

Base

- 1 - SME Base
- 2 - Flat Tie Holders
- 2 - Coupler Plates
- 1 - Nameplate, Blank
- 2 - #4 x 1/2", Wood Screws
- 4 - #6-32 x 3/8", Machine Screws
- 4 - Double-sided Foam Tapes
- 2 - Cable Ties
- 1 - #6-32, Threaded Insert

Cover

- 1 - SME Cover
- 1 - #6-32 x 1", Painted Screw
- 1 - Fiber Washer
- 1 - Faceplate Window, Clear
- 1 - Faceplate Card

Tools Required:

- Phillips Screwdriver
- Razor Knife
- Straight Screwdriver



5290 Concourse Drive • Roanoke, VA 24019 USA
Phone: 540-265-0690 • TOLL FREE 800-622-7711
Fax: 540-265-0724 • www.occfiber.com

SIDE 2